


HWC			
Description	Component Reference	Qty Per VCB	
VACUUM CONTACTOR UNIT			
	Magnet Core	MST37S4010100PL	2
	Magnet Core Shim	MBC37S4011900BL	2
	Push On Spring	MSP37S4010400PL	2
	Spring Seat	MST37S4011600PL	2
	Spring Support Post	MST37S4015700PL	2
	Spring Adjuster	MST37S4015800PL	2
	Special Lock Nut	MST37S4015900PL	2
	Coil "O" Ring	MPL37S4011500FN	2
	Coil Washer	MSH37S4011300PL	2
	Location Disc -Upper	MPL37S4016400FN	3
	Location Disc -Lower	MPL37S4016500FN	3
	Hinge Unibal	MBR37S4016300FN	3
	Unibal Clamp Plate	MSH37S4011100PL	6
	Hinge Unibal Bearing	MST37S4016200FN	2
	Stop Screw Assembly	MST37S4011000PL	1
	Armature Stop Pad	MPL37S4011200FN	1
	Armature Moulding	MSM37S1000300FN	1
	Insert	MBC37S4041900MC	2
	Tapped Plate	MST37S4016000PL	2
	Terminal Board Moulding	MSM37S2000100FN	1
	Mounting Tray	MSH37S3010100PL	1
	Main Frame Moulding	MSM37S1000200FN	1
	Armature Plate	MST37S3010300PL	1
	TQ Auxiliary Switch L/H-4NO + 4NC	MOC37S2000200FN	1
	TQ Auxiliary Switch R/H-4NO + 4NC	MOC37S2000300FN	1
	TQ Auxiliary Switch L/H-6NO + 6NC	SLWI00090-04	1
	TQ Auxiliary Switch R/H-6NO + 6NC	SLWI00090-03	1
	Operating Coil 110 V DC	ECU37S4040600FN	2
	Operating Coil 220V DC	ECU37S4040700FN	2
	Operating Coil 24-35V DC	ECU37S6730200FN	2
	GP6 Resistor Type GP6/30 -110V DC	ECU37S4040200FN	1
	GP6 Resistor Type GP6/35 -220V DC	ECU37S4046600FN	1
	GP6 Resistor Type GP6/15 -24-35V DC	ECU37SGP6-1500FN	1
	Latch-In-Mechanism with 110V DC coil	DRCN01586-02	1
	Latch-In-Mechanism with 220V DC coil	DRCN01586-01	1

HWC

Description	Component Reference	Qty Per VCB	
Latch-In-Mechanism Coil 110V DC	ECU37S4044502FN	1	
Latch-In-Mechanism Coil 220V DC	ECU37S4044501FN	1	
Latch-In-Mechanism Coil 24-35V DC	ECU37S4044503FN	1	
Description	Component Reference	Qty Per VCB	
Vacuum Interrupter Type C6B Assembly With Stud, Flex & Contact Block	SPR37SASS0000FN_S	1	
Flex Connection 400A	MCU37S0105M00PL	3	
Adaptor Block	MCU37S0106M00PL	3	
Connection Block -Lower	MCU37S0153M00PL	3	
HT Brass Stud	MBC37S4075200MC	3	
Rear Connection	MCU37S4010200PL	9	
KIT AND CARRIAGE ASSEMBLY			
 Isolating Contact -800A -Finger Type	MHU39S0523600FN	6	
 Isolating Contact -800A -Flat Type	MVIK00190-01	9	
Lower Terminal Moulding (Suitable For 1 Pair Finger Contact)**	SLWD00029-01	1	
Fuse Trip Mechanism Assembly (W/o Limit Switch) for HWX-Old	MVU25S3550800SA	1	
Fuse Trip Mechanism Assembly (W/o Limit Switch) for HWX-S	MVIK00671-01	1	
Top Guide Roller	MBR39S4323100FN	1	
 Breaker Wheel - Nylon	MPL39S0115300FN	4	
Shutter for Racking Shaft with Tripping link (with latch) for HWC-Old & HWC-S	MVIK00663-01	1	
Interlock Handle	MVIJ00028-01	1	
 Push to Trip Knob (RED) Assembly- With Spring & Housing	SPR39SASS0001FN_S	1	
On -Off Indicator	MVIK00293-01	1	
SECONDARY PLUG & SOCKET COMPONENTS			
	32 Pin Plug & Socket Assembly	MHU39S0042400FN	1
	64 Pin Plug & Socket Assembly	MHU39S00196200FN	1
	Interlock Assembly Components for Secondary Plug & Socket	MKT39S0001000CM	1
Description	Component Reference	Qty Per VCB	
HT CHAMBER ARRANGEMENT (MENTION PANEL SERIAL NO.)			
3 Phase Bus Bar Spout for HWC-Old	MEP-39-38627	1	
1 Phase Circuit Spout for HWC-Old	MEP-25-35555	3	
1-Phase Busbar Spout for R/B Phase-HWC-S	MEP-39-A0227001	2	
1-Phase Busbar Spout - Y Phase-HWC-S	MEP-39-A0227101	1	
1-Phase Circuit Spout R/Y/B Phase - HWC-S	MEP-39-A0227201	3	
Busbar Support Insulator - 40KA	MEP-39-A0147901	x	
Busbar Support Insulator - 25KA	MEP-27-30370B	x	
RACKING, SHUTTER AND EARTHING ARRANGEMENT*			

HWC

Description	Component Reference	Qty Per VCB	
	Racking Screw for HWC-Old	MVIK00064-01	1
	Racking Screw for HWC-S	MVIK00367-02	1
	Rackin Nut for HWC-Old	MBC-39-32417	1
	Rackin Nut for HWC-S	SLWA01157-01	1
	Earthing Plug	MHC-39-324252	1
	Earthing Socket	MVIK00023-01	1
	Shutter Assembly For Busbar/ Circuit Spout - 660 for HWC-C	SPC0005-01	1
	Shutter Assembly For Busbar/ Circuit Spout - 660 for HWC-S	SPC0005-02	1
	Shutter Assembly For Busbar/ Circuit Spout - 660 for HWC-Old	SPC0005-03	1
OTHER			
	Limit Switch-1NO+1NC - Service/Test Position	ESW-B-AAA00-001	8
	Rectifier Monoblock	ERC-A-A00CC-001	x
	Thermostat For Space Heater	ETH-E-B0000-001	x
	Space Heater	EHT-A-AA000-001	1