

VMX - 606

Description	Component Reference	Qty Per VCB
BREAKER KIT ASSEMBLY - 630/800/1200A		
Epoxy Body	MEP27S2046100FN	1
Modified Pin	MST27S0393803PL	1
Spider	MCS27S0714701PN	1
Opening Buffer	SJMPL27S0435701FN	1
Grommet	MPL27S0396701FN	3
Y-Phase Shroud	MPI27S4166500FN	1
Neber Washer	MPL27S0052818FN	3
Drive Beam Pair	MCS27S0298700PN	1
Dust-Proof Cover	MPL27S4019400FN	6
Drive Rod	MST27S0389700PL	1
Drive Insulator Assembly with M10 Nyloc Nut & Spl.Washer	SPR27SASS0006FN	3
VACUUM INTERRUPTER ASSEMBLY WITH FIXED CONTACT		
VG 2RG	MVU27S0VG2R00FN	3
VACUUM INTERRUPTER ASSEMBLY WITH FLEX CONNECTION		
VG 2RG - R Phase	MVU27SVG2RG0RSA	1
VG 2RG - Y Phase	MVU27SVG2RG0YSA	1
VG 2RG - B Phase	MVU27SVG2RG0BSA	1
630/800A BREAKER KIT ASSEMBLY		
Breaker Bushing	MEP27S3070400FN	3
Socket Contact	MCU27S3398201FN	6
Half Collar (Pair)	MBC27S0396901MC	3
Brass Nut	MBC27S0394102MC	3
Top Clamps with Hardwar (Pair) - R/B Phase	MBC27S0295700UP	2
Top Clamps with Hardware (Pair) - Y Phase	MBC27S0360601UP	1
Ring for Isolating Socket 630/800A	MBC27S3398202MC	6
1250A BREAKER KIT ASSEMBLY		
Breaker Bushing	MEP27S0011802FN	3
Socket Contact	SJMCMU4X734800PL	6
Conductor Between VI & Socket - 1250A (Suitable For V207G & VG2)		
- R/B Phase	MCU27S3127102PL	2
-Y Phase	MCU27S3127101PL	1
Half Collar (Pair)	MBC27S0394201MC	3
Brass Nut	MBC27S0394101MC	3
Top Clamps with Hardware (Pair) - R/B Phase	MCU27S0295601PL	2
Top Clamps with Hardware (Pair) - Y Phase	MCU27S0360602PL	1
Ring for Isolating Socket	MBC27S073483MC	6
Description	Component Reference	Qty Per VCB
BREAKER COVERS		
Top Cover	MPL27S0775901FN	1
Middle Cover	MPL27S1174601FN	1
Bottom Cover	MPL27S0714301FN	1
Clip	MPL27S0046800FN	2
MOTOR-CHARGE SPRING MECHANISM TYPE SPMX-500 FORM-AM		
Ratchet Wheel Assembly	MVIE00150-01	1
Charging Pawl Set	MST27SSD28500BL & MST27SSD28400BL	1
Handle Block Assembly	MVU27S0004900CM	1
Eccentric Drive	MST27SD214100PL	1
Release Prop	MST27S0310600BL	1
Pin for Release Prop	MST27SD209000NA	1
Bearing	MBR27SNAST800NA	1
Pin for Bearing	MST27SSD12500NA	1
Release/Closing Coil		
24VDC - CN 1176	ECO27SN117600FN	1
30VDC - CN1177	ECO27SN117700FN	1
48VDC - CN1178	ECO27SN117800FN	1
110VDC - CN1179	ECO27SN117900FN	1
220VDC - CN1180	ECO27SN118000FN	1
220VAC - CN1325	ECO27SN132500FN	1
Shunt Trip Coil		
24VDC - OG 835	ECO27SOG83500FN	1
30VDC - OG 836	ECO27SOG83600FN	1
48VDC - OG 837	ECO27SOG83700FN	1
110VDC - OG 838	ECO27SOG83800FN	1
220VDC - OG 839	ECO27SOG83900FN	1
220VAC - OG 870	ECO27SOG87000FN	1

HWU

Description	Component Reference	Qty Per VCB
Release Coil Box Assembly with Plunger -without Coil	MVU27S0005100CM	1
Trip Coil Box Assembly with Plunger - without Coil	MVU27S0005200CM	1
Trip Prop Block Assembly	MVU27S0006000CM	1
Auxiliary Switch - 12 Way Box Type	SJMVU27S3140000FN	1
Drive Link for Auxiliary Switch	MST27S3265700PL	1
Auxiliary Switch Drive Lever Assembly	MVU27S0004200CM	1
Motor Cut-Off Switch	SJSPREU27S03076FN	1
Push Rod	MBC27SD201200NA	1
Description	Component Reference	Qty Per VCB
Closing Buffer for Spring	MVIE00060-01	1
Dashpot Assembly	SJMVU27S3828900FN	1
Override Stop with Gasket	MST27S7773209PL	1
Override Stop Pin	MST27S2232800NA	1
Operation Counter	MVU27SJS5DR00FN	1
Packer (1No.)	SJMSh27S0309600PL	8
SECONDARY PLUG & SOCKET COMPONENTS		
Secondary Plug Board Assembly - 28Way	MVU27S3139900FN	1
Secondary Socket Board Assembly - 28Way	MBK-27-35887	1
PT Fuse		
HRC Fuse-PT HT Side VTF-11, 3A	EHF-A-EV000-001	3
HRC Fuse-PT HT Side VTF 6.6, 3A	EHF-B-BBA00-001	3
OPERATING TOOLS AND GAUGES		
Raising & Lowering Handle	MVM-27-355291	1
Emergency Charging Handle for Motor Mechanism	MVM-27-428931	1
OTHER		
Limit Switch-1NO+1NC - Service/Test Position	ESW-B-AAA00-001	8
Rectifier Monoblock (Mention Specifications)	ERC-A-A00CC-001	1
Busbar Support Insulator	MEP-27-30370B	x
Thermostat for Space Heater	ETH-E-B0000-001	1
Space Heater	EHT-A-AA000-001	1